



MBM275-125T REFRIGERATOR

User Manual

Images are for reference only. Products are subject to change without notice.
Please read the instruction manual carefully before use and keep it for future reference.

PLEASE READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

| | |
|---------------------------------|-----|
| Safety instructions | P2 |
| Product introduction | P5 |
| Handling and placement | P6 |
| Preparations prior to use | P7 |
| Operation notes | P8 |
| Maintenance | P11 |
| Failure analysis | P12 |
| Non-failure | P12 |
| Technical parameter | P13 |
| Packing list | P13 |

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure they do not play with the appliance.
2. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
3. This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, if they have been given supervision or instruction concerning the safe use of the appliance and understand the hazards involved. Children should not play with the appliance. Cleaning and user maintenance must not be carried out by children without supervision.
4. **WARNING:** Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
5. **WARNING:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
6. **WARNING:** Do not damage the refrigerant circuit.
7. **WARNING:** Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
8. Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
9. This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices, and other working environments;
 - Farm houses and by clients in hotels, motels, and other residential-type environments;
 - Bed and breakfast-type environments;
 - Catering and similar non-retail applications.

1. Warning

Warning: No barrier should be placed around the appliance or within the built-in structure to ensure free ventilation.

Warning: It is forbidden to speed up the defrosting process using any mechanical equipment or by any method other than that recommended by the manufacturer.

Warning: Do not damage the refrigerant circuit.

Warning: Do not use any electrical appliances inside the food chamber of the appliance unless they are of the type recommended by the manufacturer.

Warning: Do not place liquid beverages or food contained in glass containers in the freezing chamber to prevent breakage and shattering.

Warning: If the refrigerator is powered off, it should be powered on again 5 minutes later to prevent damage to the compressor.

Warning: If any live part, abnormal noise, smell, smoke, or other abnormalities are noticed during use, it is essential to immediately power off the appliance and promptly contact the after-sales service department of the company.

Warning: Avoid placing your finger or hand under the refrigerator, especially at the rear bottom, as sharp objects may cause injury.

Warning: Children must not play or climb on the refrigerator. Parents must supervise children to prevent potential danger.

Warning: Avoid placing your hand between the doors to open or close them to prevent jamming your fingers. Always use the door handle to open or close the door.

For refrigerating appliances with climate class

Depending on the climate class, This refrigerating appliance is intended to be used at ambient temperatures range as specified following table.

The climate class can be found on the rating plate. The product may not operate properly at temperatures outside of the specific range.

You can find climate class on label inside of your refrigerator.

Effective temperature range

The refrigerator is designed to operate normally in the temperature range specified by its class rating.

| Class | symbol | Ambient Temperature range (°C) |
|--------------------|--------|--------------------------------|
| Extended Temperate | SN | +10 to +32 |
| Temperate | N | +16 to +32 |
| Subtropical | ST | +16 to +38 |
| Tropical | T | +16 to +43 |

NOTE

The cooling performance and power consumption of the refrigerator may be affected by the ambient temperature, the door-opening frequency, and the location of the refrigerator, We recommend adjusting the temperature settings as appropriate.

Safety instructions



Warning: Risk of fire / flammable materials

Warning: When positioning the appliance, ensure the supply cord is not trapped or damaged.

Warning: Avoid placing multiple portable socket outlets or power supplies at the rear of the appliance.

Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances. Prolonged door opening can lead to a significant increase in temperature within the appliance compartments.

Regularly clean surfaces that come into contact with food and accessible drainage systems. Clean water tanks if they have not been used for 48 hours; flush the water system connected to a water supply if water has not been drawn for 5 days.

Store raw meat and fish in suitable containers in the refrigerator to prevent contact with or dripping onto other food.

Two-star frozen-food compartments are suitable for storing pre-frozen food, storing or making ice-cream and making ice cubes.

One-, two-, and three-star compartments are not suitable for freezing fresh food.

If the refrigerating appliance is left empty for extended periods, switch it off, defrost, clean, dry, and leave the door open to prevent mould development within the appliance.

2. Cautions

Cautions: The power supply for this product must match the power supply stated on the nameplate, and a standard independent 3-hole socket rated above 10A and reliably grounded must be used. Avoid sharing one socket among multiple appliances to prevent overheating and potential fire hazards.

Cautions: Avoid pulling the power wire by hand. Always hold and unplug the power connector from the socket to disconnect the power supply. Do not touch the power wire or connector with wet hands to prevent the risk of electric shock.

Cautions: Do not allow the power wire to be squeezed by the refrigerator or any heavy load, and avoid extreme bending of the power wire.

Damage or peeling of the power wire may lead to fire or electric shock hazards.

If the power wire is broken or cut, please contact the after-sales service department immediately for assistance.

Cautions: Do not store any flammable or explosive materials, corrosive acids, or alkaline substances in the refrigerator.

Safety instructions

Cautions: Do not use the refrigerator in rainy conditions or under direct sunlight.

Cautions: Do not place containers with fluids on the refrigerator, as breakage or overturning of the container may compromise the electrical insulation of the refrigerator, leading to electric shock or fire hazards.

Cautions: The refrigerator must not be disassembled or modified without permission. The repair of refrigerator must be performed by the specialist.

Cautions: In the event of a leakage of any flammable gas such as coal gas, first, close the leaking valve, then open the window for ventilation. Do not unplug the refrigerator connector immediately to avoid the risk of fire or explosion due to electric sparks.

Cautions: Refrigerating appliances, especially refrigerator-freezers Type I, may not operate consistently if sited for an extended period below the cold end of the temperature range for which the appliance is designed. This may result in defrosting of contents or the temperature becoming too warm in the frozen food compartment.

Cautions: Effervescent drinks should not be stored in food freezer compartments or cabinets, or in low-temperature compartments or cabinets. Additionally, some products, such as iced water, should not be consumed when excessively cold.

Cautions: Do not exceed the storage times recommended by food manufacturers for any kind of food.


Cautions: Take precautions to prevent an undue rise in the temperature of frozen food while defrosting the refrigerating appliance.

Cautions: The rise in temperature of frozen food during manual defrosting, maintenance, or cleaning may reduce its storage life.

Cautions: Ensure proper care for frozen food storage during extended periods when the refrigerating appliance is not running, such as during a power outage or refrigeration system failure.

Cautions: Steps to take when temporarily or permanently switching off the refrigerating appliance include emptying, cleaning, and drying it, and propping the door(s) or lid(s) ajar.

Product introduction



The pictures are for reference only. Please refer to the object

Features


- Computer intelligent temperature control ; air cooling and frost free.
- Environmental-friendly refrigerant,It applies materials without CFC, R600a environmental-friendly materials. 80% of the main materials can be recycled;
- Transparent drawers with novel appearances and their internal foods can be clear at a glance;
- The tempered glass refrigeration shelves are height adjustable, wear proof, heat-proof and practical;
- The concealed condenser applies flat back design. It has perfect and coordinated style which is simple, easy to clean and high utility rate of space;
- This product adopts the efficient mute compressor of international brand and special case foaming technology, and features low noise, low energy consumption, and is more suitable for family and commercial purposes.

Friendly reminder:


If your product is an improved product, it may differ slightly from the instructions provided. However, rest assured that its performance and application method remain unchanged. You can confidently proceed with its usage.

Handling and placement


Certain space shall be left around the refrigerator, shown in the figure.




While handling, avoid contact between the refrigerator door side and handling tools.




Position the refrigerator in a dry, well-ventilated area, away from direct sunlight and heat sources.




Place the refrigerator on a flat and stable surface. If the ground is uneven, adjust the leveling legs to ensure stability.



Avoid placing the refrigerator in excessively cold environments where freezing may occur.



Removing the foam base aids in bottom heat dissipation and reduces the risk of fire.




Friendly reminder:

- When handling the refrigerator, at least two persons are required: one to lift the top of the rear part, and the other to handle the bottom. If one part alone is clamped, it can be dangerous and may cause accidents.
- When moving the refrigerator, the lower runner may damage and scratch the floor. If you need to move the refrigerator over a long distance, use adhesive tape to secure the internal accessories to prevent them from getting damaged by crashing into each other.
- Place the refrigerator in a position with minimal vibration or where it is least exposed to vibration. For users in areas prone to earthquakes, ensure the refrigerator is fixed against a wall or pole to prevent accidents.
- Leave sufficient clearance around the refrigerator. If the clearance is too small or if goods are placed on top or too close to the sides, or if items are pasted onto the sides, it can affect the refrigerator's heat dissipation, leading to unnecessary electricity wastage and potential damage to walls and other items. Contact between the back of the refrigerator and the wall can also cause vibration and noise.
- Adjust the front part and adjusting leg of the refrigerator to level it. An unlevel refrigerator can cause vibration and noise.

Handling and placement

This refrigerating appliance is not intended to be used as a built-in appliance
The outline dimension of the product and the space needed by the use of product are shown in the following pictures:




Unit:mm

| Outline dimension of product | | Space needed by the use of product | | Total space needed by the use of product | |
|------------------------------|-----|------------------------------------|-----------|--|-----------|
| L1 | W1 | L2 | W2 | L3 | W3 |
| 615 | 545 | $>L1+100$ | $>W1+200$ | $>L1+600$ | $>W1+400$ |

Preparations prior to use

1. Remove all packing assemblies such as case fixing tape etc., especially the foam base.
2. Use warm wet cloth to clean both interior and exterior of the refrigerator, (neutral detergent can be added in warm water).
3. After leveling and cleaning the refrigerator, stand it for about 5 hours before plugging the power plug for powering on, and cool the refrigerator for 2 to 3 hours before storing foods.

1. Remove fixing tape




In hot summer, 24 hours are needed to fully freeze the food. Check the refrigerating condition on the second day.


2. Connect to power



3. Store food after connecting to power for 2-3 hours



The plastics deodorant will disappear automatically after freezing for a while.



Power on for the first time

The refrigerating chamber will run at 5 °C when it is powered on for the first time.

Child lock function

When there is no key operation on the display panel within 30 seconds, the display screen will go out and the child lock function will automatically start. In this state, any key can be pressed to wake up the display screen and make it light up. Keep pressing the "Temperature control switch" key for 3 seconds to unlock the keyboard.

Regulation of temperature inside the refrigerating chamber

In the unlocked state, press the "Temperature control switch" key to regulate the temperature inside the refrigerating chamber. The temperature inside the refrigerating chamber will cycle between "02" - "04" - "05" - "06" - "08" - "Power cool" - "Power Freeze" - "Holiday" - "02". After selecting the appropriate temperature, stop the key operation and wait for 5 seconds, then the set temperature will stop flashing and be confirmed.

Power cool function

In the unlocked state, press the "Temperature control switch" key repeatedly until the "Power cool" icon flashes, stop the key operation and wait for 5 seconds, then the power cool function of the refrigerating chamber will start. The corresponding temperature in the power cool state will be 2 °C.

Holiday function

In the unlocked state, press the "Temperature control switch" key repeatedly until the "Smart" icon flashes, stop the key operation and wait for 5 seconds, then the smart function will start. The corresponding temperature in the smart state will be 5 °C.

Power Freeze function

In the unlocked state, press the "Temperature control switch" key repeatedly until the "Power Freeze" icon flashes, stop the key operation and wait for 5 seconds, then the power cool function of the refrigerating chamber will start. The corresponding temperature in the power cool state will be -32 °C.

Door alarm

If the refrigerating chamber is not closed tightly or it keeps open for more than 1 minute, the "Door alarm" icon will flash to remind, and at the same time it will beep. Any key can be pressed to temporarily stop the alarm, but it will alarm again 1 minute later. Close the refrigerating door tightly to stop the flashing and alarm.

Operation notes

Foods storage

Refrigerating chamber (2°C~8°C)

--The refrigerating chamber is mainly used for storing short-term foods, like milk, eggs and bottled drink.

--Vegetables and fruits should be stored in the vegetable and fruit box to prevent loss of moisture.

--Cooked food should be placed in storage bags before storing them in the refrigerator to prevent an increase in energy consumption.

Freezing chamber (-24°C~-15°C)

--The freezing chamber is utilized for storing items intended for long-term preservation.

--Fish and meat to be frozen shall be cut into small pieces, packaged with preservative bags separately and then put into the frozen drawer.

--Placing glass or sealed containers with liquid in the freezing chamber is prohibited to prevent the risk of cracking or explosion.

--Fresh food should not be stored together with frozen food to maintain optimal storage conditions and prevent contamination.



--Do not place food close to inside wall in freezer lest food and wall should be frozen together.

★★ Warm tips:

Stored food should not obstruct the air duct outlet and return port to avoid compromising the refrigerating effect. Additionally, before placing food in the refrigerator, ensure that overheated water and food have cooled to room temperature.

Ice-making (If the appliance has it)

Fill the ice-making box with 4/5 water and put the box into the freezing chamber. After the water in the box turns into ice, twist the box slightly to separate the ice from the box. However, don't bend the box. When separating the ice, wrap the box with dry box to avoid finger frostbite.



Note:

Considering that the temperature of the refrigerator liner is relatively low, it is not recommended to use the refrigerator without its crisper. If food is refrigerated with the crisper removed, the food may directly contact the surface of the refrigerator liner, resulting in the risk of food being frozen.

Operation keys

Disassembly and assembly method of accessory

--Glass shelf in the refrigerating chamber: the height of the shelf is adjustable, which facilitates the storage of articles with different volumes. Pull the shelf outwardly and upwardly in a slight way to take out.


--Fruit and vegetable box: for storing vegetables and fruits. It can be taken out by pulling outwardly.

--Drawer in the freezing chamber: storing foods to be preserved for long-term, such as meat and fish. It can be taken out by pulling outwardly and lifting upwardly.


Kindly tips: It is recommended to put into the large piece of meat after being cut into small pieces, to avoid difficult cutting after being frozen. The quick-freezing foods shall be distributed uniformly and stored together after being frozen.

--Bottle pedestal at the refrigerating door: storing eggs, various bottled drinks and other sundries. It can be taken out by being lifted up slightly.

Note: when disassembling the bottle pedestal in the refrigerating door, avoid pulling it out forcibly to prevent damage to the refrigerator.



Take out by pulling upwardly and outwardly in a slight way



Remove by gently pulling it outward and upward.

Care and Maintenance

It is recommended to perform refrigerator maintenance once a month.

Use a damp cloth or neutral detergent (cleanser essence) to wipe away any oil contamination and dirt. After cleaning, ensure to thoroughly wipe off any residue of the detergent.

--Do not use alkaline detergent, soap powder, gasoline and alcohol, talcum powder etc.; otherwise the coats or plastics may be damaged;

--Regularly clean the refrigerator body and clear the ground dusts to keep the refrigerator clean.


Inspections after maintenance:

Check for any damages to the power line and plug. Look for dust on the power plug. Feel for abnormal heat on the plug. Check if the socket is loose. Ensure that the plug is fully inserted.

Note:

If the power line and plug are damaged and there is dust present, there is a risk of electric shock or fire.

After unplugging the plug, 5 minutes must pass before re-plugging it; Do not put your hands under the refrigerator to avoid getting hurt.



Unplug the refrigerator plug before cleaning



Please use neutral detergent

Failure analysis

The following items shall be inspected before occurring failures which require maintenance:

Failures: Refrigerator does not work, The refrigeration effect is poor

Causes:

1. Check the connection of the power supply.
2. Check whether the refrigerator is exposed to direct sunlight or if there is a heat source nearby.
3. Check whether there is adequate heat dissipation space around the refrigerator.

Remedies:

1. Ensure the power supply is properly connected.
2. Move the refrigerator to a location without direct sunlight or heat sources nearby.
3. Leave adequate space between the refrigerator and the wall for proper heat dissipation.

Failures: Foods in refrigerating chamber are frozen

Causes: 1. Check whether the setting temperature is too low. 2. Additionally, rearrange foods with high water content to the door side of the glass shelf.

Remedies: 1. Adjust the temperature settings accordingly to ensure they are adequately increased. 2. Rearrange foods with high water content to the door side of the glass shelf.

Failures: There is abnormal sound in refrigerator

Causes: 1. Check whether the bottom of refrigerator is stable. 2. Check whether the refrigerator is too close to the wall. 3. Check whether the refrigerator touches other objects.

Remedies: 1. Adjust the bottom adjusting leg to stabilize the refrigerator. 2. Leave sufficient space around refrigerator. 3. Remove the obstacles.

Failures: There is abnormal odor in refrigerator

Causes: 1. Check whether the foods are sealed for storage. 2. Check whether the refrigerator is clean. 3. Check whether the foods have been stored for too long.

Remedies: 1. Sealed foods for storage. 2. Regularly clean the refrigerator. 3. Do not store foods for too long.

Non-failures

Phenomenon: The surface between the refrigerating chamber and freezing chamber feels warm or hot on two sides and the spacing part.

Cause: The refrigerator pipes (such as condenser and anti-fog pipes) are located on two sides and the front part of the refrigerator for heat dissipation and to prevent condensation.

Phenomenon: The refrigerator door is too tight and not easy to open.

Cause: When the refrigerator door is closed and immediately reopened, hot air enters the refrigerator and contracts, creating a pressure difference. This makes it difficult to open the door immediately, but it becomes easier after some time.

Phenomenon: Water ripples are observed in the refrigerator.

Cause: The sound of water ripples can occur when the compressor starts or stops, as well as when water is produced during the defrosting process.

Phenomenon: There is a humming sound in the refrigerator.

Cause: The compressor running produces this sound. If the refrigerator is not leveled, the sound may be louder. Additionally, the shrinkage and swelling of the case, especially when it's cold or the door is opened, can also contribute to this sound.

Phenomenon: Condensation or frosting is observed on the freezing chamber door surface or food surface.

Cause: High temperature or humidity around the refrigerator; prolonged opening of the door; foods with high water content that are not sealed or tightly wrapped.

Phenomenon: Condensation is present on the built-in light surface.

Cause: The light generates heat when illuminated, and if the door is left open for an extended period, a temperature difference occurs, leading to condensation on the light case.

Phenomenon: Condensation and water mist are present on the refrigerator body.

Cause: High humidity around the refrigerator causes moisture in the air to accumulate in the case, resulting in condensation.

Technical parameter

| | | | | | | | |
|-------------------------------|----------------|--|--|--|--|--|--|
| Climate type | SN/N/ST/T | | | | | | |
| Electric shock resistance | I | | | | | | |
| Star sign | ★☆☆ | | | | | | |
| Total Storage Volume | 275L | | | | | | |
| Storage Volume of Freezer | 72L | | | | | | |
| Power type | 185-240V~/50Hz | | | | | | |
| Rated current | 0.7A | | | | | | |
| Power consumption | 0.76kW•h/24h | | | | | | |
| Lamp power | 1.5W | | | | | | |
| Weight | 54kg | | | | | | |
| Dimension (W x D x H mm) | 545x615x1825 | | | | | | |
| Refrigerant and charge amount | R600a,54g | | | | | | |
| Noise level (dB(A) re 1 pW) | 42 | | | | | | |

Packing list

| | | | | | | | |
|-------------------------------|---|--|--|--|--|--|--|
| Refrigerator shelf | 3 | | | | | | |
| Fruit and vegetable box cover | 1 | | | | | | |
| Fruit and vegetable box | 1 | | | | | | |
| Ice-making box | 1 | | | | | | |
| Egg box | 1 | | | | | | |
| Refrigerator bottle holder | 3 | | | | | | |
| Freezer drawer | 3 | | | | | | |
| Operating instruction | 1 | | | | | | |

The product has multiple configurations, please refer to the actual product for details.

المعلومات التقنية

| | | | | | | | |
|--|--|--|--|--|--|-------------------------------|---------------------------------------|
| | | | | | | SN/N/ST/T | نوع المناخ |
| | | | | | | I | مقاومة الصدمات الكهربائية |
| | | | | | | *** | علامة النجمة |
| | | | | | | 275 لترًا | إجمالي حجم التخزين |
| | | | | | | 72 لترًا | حجم تخزين الفريزر |
| | | | | | | 185-240V~/50Hz هرتز | نوع الطاقة |
| | | | | | | 0.7 أمبير | التيار المقنن |
| | | | | | | 0.76 كيلو واط/ساعة/24 ساعة | استهلاك الطاقة |
| | | | | | | 1.5 واط | طاقة المصباح |
| | | | | | | 54 كجم | الوزن |
| | | | | | | 545x615x1825 | الأبعاد (العرض × العمق × الارتفاع مم) |
| | | | | | | R600a,54g | المبرد وكمية الشحن |
| | | | | | | 42 | مستوى الضوضاء (dB(A) re 1 pW) |

قائمة التعبئة

| | | | | | | | |
|--|--|--|--|--|--|---|------------------------------|
| | | | | | | 3 | رف التلاجة |
| | | | | | | 1 | غطاء صندوق الفواكه والخضروات |
| | | | | | | 1 | صندوق الفاكهة والخضروات |
| | | | | | | 1 | صندوق صنع الثلج |
| | | | | | | 1 | صندوق البيض |
| | | | | | | 3 | حامل زجاجات التلاجة |
| | | | | | | 3 | درج الفريزر |
| | | | | | | 1 | تعليمات التشغيل |

يحتوي المنتج على توكيونات متعددة، يرجى الرجوع إلى المنتج الفعلي للحصول على التفاصيل.

يجب فحص العناصر التالية قبل حدوث الأعطال التي تتطلب الصيانة:

الإخفاقات: الثلجة لا تعمل، تأثير التبريد ضعيف

الأسباب:

1. تحقق من توصيل مصدر الطاقة.

2. تحقق مما إذا كانت الثلجة معرضة لأشعة الشمس المباشرة أو إذا كان هناك مصدر حرارة قريب.

3. تأكد من وجود مساحة كافية لتبريد الحرارة حول الثلجة.

التدابير:

1. تأكد من توصيل مصدر الطاقة بشكل صحيح. 2. قم بنقل الثلجة إلى مكان لا يتعرض لأشعة الشمس المباشرة أو مصادر الحرارة القريبة. 3. اترك مساحة كافية بين الثلجة والحائط لتبريد الحرارة بشكل جيد.

الإخفاقات: يتم تجميد الأطعمة الموجودة في حجرة التبريد

الأسباب: 1. تحقق مما إذا كانت درجة حرارة الإعداد منخفضة جدًا.

2. بالإضافة إلى ذلك، قم بإعادة ترتيب الأطعمة التي تحتوي على نسبة عالية من الماء إلى جانب الباب من الرف الزجاجي.

التدابير: 1. قم بضبط إعدادات درجة الحرارة وفقًا لذلك للتأكد من زيادتها بشكل كافي.

2. قم بإعادة ترتيب الأطعمة التي تحتوي على نسبة عالية من الماء إلى جانب الباب من الرف الزجاجي.

الإخفاقات: هناك صوت غير طبيعي في الثلجة

الأسباب: 1. تحقق مما إذا كان الجزء السفلي من الثلجة مستقرًا.

2. تحقق مما إذا كانت الثلجة قريبة جدًا من الحائط. 3. تحقق مما إذا كانت الثلجة تلامس أشياء أخرى.

التدابير: 1. اضبط ساق الضبط السفلية لتثبيت الثلجة. 2. اترك مساحة كافية حول الثلجة. 3. قم بإزالة العوائق.

الإخفاقات: هناك رائحة غير طبيعية في الثلجة

الأسباب: 1. التحقق مما إذا كانت الأطعمة مغلقة للتخزين. 2. تحقق ما إذا كانت الثلجة نظيفة. 3. تحقق مما إذا كانت الأطعمة قد تم تخزينها لفترة طويلة.

التدابير: 1. الأطعمة مغلقة للتخزين. 2. نظف الثلجة بانتظام. 3. لا تقم بتخزين الأطعمة لفترة طويلة.

عدم الفشل

ظاهرة: يشعر السطح بين حجرة التبريد وحجرة التجميد بالدفء أو الحرارة على الجانبين والجزء الفاصل.

السبب: توجد أنابيب الثلجة (مثل المكثف وأنابيب منع الضباب) على جانبيين والجزء الأمامي من الثلجة لتبريد الحرارة ومنع التكثيف.

ظاهرة: باب الثلجة محكم للغاية وليس من السهل فتحه.

السبب: عندما يتم إغلاق باب الثلجة ثم إعادة فتحه على الفور، يدخل الهواء الساخن إلى الثلجة وينقل، مما يخلق فرقًا في الضغط. وهذا يجعل فتح الباب على الفور أمرًا صعبًا، لكن الأمر يصبح أسهل بعد مرور بعض الوقت.

ظاهرة: تمت ملاحظة موجات الماء في الثلجة.

السبب: يمكن أن يحدث صوت تموجات الماء عند بدء تشغيل الضاغطة أو إيقافه، وكذلك عند إنتاج الماء أثناء عملية إزالة الجليد.

ظاهرة: هناك صوت طنين في الثلجة.

السبب: ينتج تشغيل الضاغطة هذا الصوت. إذا لم تكن الثلجة مستوية، فقد يكون الصوت أعلى. بالإضافة إلى ذلك، فإن انكماش وتورم الغلاف، خاصة عندما يكون الجو باردًا أو عندما يكون الباب مفتوحًا، يمكن أن يساهم أيضًا في هذا الصوت.

ظاهرة: يتم ملاحظة التكثيف أو التجميد على سطح باب حجرة التجميد أو سطح الطعام.

السبب: ارتفاع درجة الحرارة أو الرطوبة حول الثلجة؛ فتح الباب لفترة طويلة؛ الأطعمة التي تحتوي على نسبة عالية من الماء والتي ليست مغلقة أو مبردة بإحكام.


ظاهرة: يوجد تكاثف على سطح الضوء المدمج.

السبب: يتولد عن ضوء حرارة عند إضاءته، وإذا ترك الباب مفتوحًا لفترة طويلة، يحدث فرق في درجة الحرارة، مما يؤدي إلى تكاثف على غلاف الضوء.


ظاهرة: يوجد تكاثف ورذاذ ماء على جسم الثلجة.

السبب: تؤدي الرطوبة العالية حول الثلجة إلى تراكم الرطوبة الموجودة في الهواء داخل الغلاف، مما يؤدي إلى التكثيف.

طريقة فك وتركيب الملحقات




قم بإخراج عن طريق السحب للأعلى وللخارج بشكل طفيف



قم بالإزالة عن طريق السحب بلطف للخارج وللأعلى.

- الرف الزجاجي في غرفة التبريد: ارتفاع الرف قابل للتعديل مما يسهل تخزين المواد بأحجام مختلفة. اسحب الرف للخارج وللأعلى بطريقة بسيطة لإخراجه.
- صندوق الفواكه والخضروات: لتخزين الخضار والفواكه. يمكن إخراجه عن طريق السحب إلى الخارج.
- درج في حجرة التجميد: لتخزين الأطعمة التي سيتم حفظها لفترة طويلة، مثل اللحوم والأسماك. يمكن إخراجه عن طريق السحب للخارج والرفع للأعلى.
- نصائح مفيدة: يوصى بوضع قطعة اللحم الكبيرة بعد تقطيعها إلى قطع صغيرة، لتجنب صعوبة التقطيع بعد التجميد. يجب توزيع الأطعمة سريعة التجميد بشكل موحد وتخزينها معاً بعد تجميدها.
- قاعدة القوارير عند باب الثلاجة: لتخزين البيض ومختلف المشروبات المعبأة في قوارير وغيرها من المنفوقات. يمكن إخراجه عن طريق رفعها قليلاً.
- ملاحظة: عند تفكيك قاعدة الزجاجاة الموجودة في باب الثلاجة، تجنب سحبها للخارج بالقوة لتجنب إتلاف الثلاجة.

الرعاية والصيانة



افصل قابس الثلاجة قبل التنظيف

- من المستحسن إجراء صيانة الثلاجة مرة واحدة شهرياً.
- استخدم قطعة قماش مبللة أو منظف محايد (منظف مركز) لمسح أي تلوث زيتي أو أوساخ. بعد التنظيف، تأكد من مسح أي بقايا من المنظف جيداً.
- لا تستخدم المنظفات القلوية ومسحوق الصابون والبنزين والكحول وبودرة التلك وما إلى ذلك؛ وإلا فقد تتلف الطلاء أو المواد البلاستيكية؛
- قم بتنظيف جسم الثلاجة بانتظام وإزالة الغبار الأرضي للحفاظ على نظافة الثلاجة.
- الفحص بعد الصيانة:

تحقق من عدم وجود أي ضرر في خط الطاقة والمقيس. ابحث عن الغبار على قابس الطاقة. اشعر بالحرارة غير الطبيعية في القابس. تحقق مما إذا كان المقيس فضفاضاً. تأكد من إدخال القابس بالكامل.

ملاحظة:

- في حالة تلف خط الطاقة والمقيس ووجود الغبار، يكون هناك خطر التعرض لصدمة كهربائية أو حريق.
- بعد فصل القابس، يجب أن تمر 5 دقائق قبل إعادة توصيله؛
- لا تضع يديك تحت الثلاجة حتى لا تصاب بأذى.



يرجى استخدام منظف محايد

تخزين الأطعمة

حجرة التبريد (2 درجة مئوية ~ 8 درجة مئوية)


- تستخدم حجرة التبريد بشكل أساسي لتخزين الأطعمة قصيرة الأجل، مثل الحليب والبيض والمشروبات المعبأة في زجاجات.
- يجب تخزين الخضار والفواكه في صندوق الخضار والفواكه لمنع فقدان الرطوبة.
- يجب وضع الأطعمة المطبوخة في أكياس تخزين قبل تخزينها في الثلاجة لمنع زيادة استهلاك الطاقة.

حجرة التجميد (24- درجة مئوية ~ 15- درجة مئوية)

- يتم استخدام حجرة التجميد لتخزين العناصر المخصصة للحفاظ على المدى الطويل.
- يجب تقطيع الأسماك واللحوم المراد تجميدها إلى قطع صغيرة وتعبئتها بأكياس حافظة بشكل منفصل ثم وضعها في درج التجميد.
- يمنع وضع الأوعية الزجاجية أو المغلقة التي تحتوي على سوائل داخل حجرة التجميد لتجنب خطر التشقق أو الانفجار.
- لا ينبغي تخزين الأطعمة الطازجة مع الأطعمة المجمدة للحفاظ على ظروف تخزين مثالية ومنع الثلوث.
- لا تضع الطعام بالقرب من الجدار الداخلي في الفريزر حتى لا يتم تجميد الطعام والجدار معًا.

★★ نصائح ودية:

يجب ألا تعيق الأطعمة المخزنة مخرج مجرى الهواء ومنفذ العودة لتجنب المساس بتأثير التبريد. بالإضافة إلى ذلك، قبل وضع الطعام في الثلاجة، تأكد من أن الماء الساخن والطعام قد بردا إلى درجة حرارة الحجرة.



صنع الثلج (إذا كان الجهاز مزودًا به)

املا صندوق صنع الثلج بـ 4/5 من الماء ثم ضع الصندوق في حجرة التجميد. بعد أن يتحول الماء الموجود في الصندوق إلى ثلج، قم بلف الصندوق قليلاً لفصل الثلج عن الصندوق. ومع ذلك، لا تنتهي الصندوق. عند فصل الثلج، قم بتغليف الصندوق بصندوق جاف لتجنب قسمة الصقيع بالإصبع.



ملاحظة:

بما أن درجة حرارة بطانة الثلاجة منخفضة نسبيًا، فلا يُنصح باستخدام الثلاجة بدون الجزء المخصص للأطعمة المبردة. إذا تم تبريد الطعام دون إزالة الغطاء الخالي من الخضراوات، فقد يلامس الطعام سطح بطانة الثلاجة مباشرة، مما يؤدي إلى خطر تجميد الطعام.

التشغيل لأول مرة

ستعمل حجرة التبريد على درجة حرارة 5 عند تشغيلها لأول مرة.

وظيفة Child lock

عند عدم وجود أي تشغيل لمفتاحي على لوحة العرض خلال 30 ثانية، ستنتفي شاشة العرض وستبدأ وظيفة Child lock تلقائيًا. في هذه الحالة، يمكن الضغط على أي مفتاح لإيقاف شاشة العرض وإضاءتها. استمر في الضغط على مفتاح "Temperature control switch" لمدة 3 ثوانٍ لفتح لوحة المفاتيح.

تنظيم درجة الحرارة داخل حجرة التبريد

في الحالة غير المغلقة، اضغط على مفتاح "Temperature control switch" لتنظيم درجة الحرارة داخل حجرة التبريد. ستتراوح درجة الحرارة داخل حجرة التبريد بين "02" - "04" - "05" - "06" - "08" - "Power cool" - "Power Freeze" - "Holiday" - "02". بعد تحديد درجة الحرارة المناسبة، أوقف تشغيل المفتاح وانتظر لمدة 5 ثوانٍ، ثم ستتوقف درجة الحرارة المحددة عن الوميض وسيتم تأكيدها.

وظيفة Power cool

في حالة عدم الفقل، اضغط على مفتاح "Temperature control switch" بشكل متكرر حتى يوميض رمز "Power cool"، وأوقف تشغيل المفتاح وانتظر لمدة 5 ثوانٍ، ثم تبدأ وظيفة Power cool لحجرة التبريد. ستكون درجة الحرارة المقابلة في حالة Power cool 2.

وظيفة Holiday

في حالة عدم الفقل، اضغط على مفتاح "Temperature control switch" بشكل متكرر حتى يوميض رمز "Smart"، وأوقف تشغيل المفتاح وانتظر لمدة 5 ثوانٍ، ثم ستبدأ الوظيفة الذكية. ستكون درجة الحرارة المقابلة في الحالة الذكية 5.

وظيفة Power Freeze

في حالة عدم الفقل، اضغط على مفتاح "Temperature control switch" بشكل متكرر حتى يوميض رمز "Power Freeze"، وأوقف تشغيل المفتاح وانتظر لمدة 5 ثوانٍ، ثم تبدأ وظيفة Power cool لحجرة التبريد. ستكون درجة الحرارة المقابلة في حالة Power cool -32.

إنذار الباب


إذا لم يتم إغلاق حجرة التبريد بإحكام أو بقيت مفتوحة لأكثر من دقيقة، فسوف يوميض رمز "Door alarm" للتحذير، وفي نفس الوقت ستصدر صوت تنبيه. يمكن الضغط على أي مفتاح لإيقاف التنبيه مؤقتًا، لكنه سيصدر تنبيهًا مرة أخرى بعد دقيقة واحدة. أغلق باب الثلاجة بإحكام لإيقاف الوميض والإنذار.




جهاز التبريد هذا غير مخصص للاستخدام كجهاز تبريد مدمج

تظهر الأبعاد الخارجية للمنتج والمساحة المطلوبة لاستخدام المنتج في الصور التالية:


الأبعاد التفصيلية للمنتج



المساحة المطلوبة لاستخدام المنتج



المساحة الإجمالية المطلوبة لاستخدام المنتج



| الأبعاد التفصيلية للمنتج | | المساحة المطلوبة لاستخدام المنتج | | المساحة الإجمالية المطلوبة لاستخدام المنتج | |
|--------------------------|-----|----------------------------------|---------|--|---------|
| L1 | W1 | L2 | W2 | L3 | W3 |
| 615 | 545 | L1+100< | W1+200< | L1+600< | W1+400< |

الاستعدادات قبل الاستخدام

1. قم بإزالة جميع مجموعات التغليف مثل شريط تثبيت العلب وما إلى ذلك، وخاصة القاعدة الرغوية.
2. استخدم قطعة قماش مبللة دافئة لتنظيف الجزء الداخلي والخارجي للثلاجة (يمكن إضافة منظف محايد إلى الماء الدافئ).
3. بعد تسوية الثلاجة وتنظيفها، اتركها لمدة ساعتين تقريباً قبل توصيل قابس الطاقة لتشغيلها، و قم بتبريد الثلاجة لمدة ساعتين إلى ثلاث ساعات قبل تخزين الأطعمة.

3. قم بتخزين الطعام بعد التوصيل بالتيار الكهربائي لمدة تتراوح من ساعتين إلى ثلاث ساعات

تدري: عدم فتح الباب بشكل متكرر يوفر الكهرباء.


سوف تخففي رائحة البلاستيك تلقائياً بعد التجميد لفترة من الوقت.

2. قم بتوصيل الطاقة

1. قم بإزالة شريط التثبيت

امسح بقطعة قماش دافئة ورطبة

في فصل الصيف الحار، هناك حاجة إلى 24 ساعة لتجميد الطعام بالكامل. قم بالتحقق من حالة التبريد في اليوم التالي.



تذكير ودي:

عند التعامل مع الثلاجة، يلزم وجود شخصين على الأقل: أحدهما لرفع الجزء العلوي من الجزء الخلفي، والآخر للتعامل مع الجزء السفلي. إذا تم تثبيت جزء واحد فقط، فقد يكون ذلك خطيراً وقد يسبب حوادث.

عند تحريك الثلاجة، قد يؤدي المجرى السفلي إلى إتلاف وخدش الأرضية. إذا كنت بحاجة إلى نقل الثلاجة لمسافة طويلة، فاستخدم شريطاً لاصقاً لتأمين الملحقات الداخلية لمنع تعرضها للتلف بسبب الاصطدام ببعضها البعض.

ضع الثلاجة في مكان به أقل قدر من الاهتزاز أو حيث تتعرض للاهتزاز بأقل قدر ممكن. بالنسبة للمستخدمين في المناطق المعرضة للزلازل، تأكد من تثبيت الثلاجة على حائط أو عمود لمنع وقوع الحوادث.

اترك مساحة خالية كافية حول الثلاجة. إذا كانت المساحة الخالية صغيرة جداً أو إذا تم وضع البضائع في الأعلى أو بالقرب من الجوانب، أو إذا تم لصق أغراض على الجانبين، فقد يؤثر ذلك على تبريد الحرارة في الثلاجة، مما يؤدي إلى هدر غير ضروري للكهرباء والحاق أضرار محتملة بالجدران والأغراض الأخرى. يمكن أن يؤدي التلامس بين الجزء الخلفي من الثلاجة والحائط أيضاً إلى حدوث اهتزاز وضوضاء.

اضبط الجزء الأمامي وأرجل الثلاجة لتسويتها. يمكن أن تتسبب الثلاجة غير المستوية في حدوث اهتزاز وضوضاء.



الصور هي للإشارة فقط. يرجى الرجوع إلى العنصر نفسه

الميزات

- التحكم الذكي في درجة الحرارة بواسطة الكمبيوتر؛ تبريد الهواء وخالي من الصقيع.
- مبرد صديق للبيئة، يستخدم مواد خالية من مركبات الكلوروفلوروكربون، ومواد R600a الصديقة للبيئة. يمكن إعادة تدوير 80% من المواد الرئيسية؛
- أدرج شفافة ذات مظهر جديد ويمكن رؤية الأطعمة الداخلية فيها بوضوح في لمح البصر؛
- أرفف التبريد الزجاجية المقواة قابلة لتعديل ارتفاعها ومقاومة للتآكل ومقاومة للحرارة وعملية؛
- يستخدم المكثف المخفي تصميم ظهر مسطح. يتمتع بأسلوب مثالي ومنسق وهو بسيط وسهل التنظيف ومعدل فائدة مرتفع للمساحة؛
- يعتمد هذا المنتج على ضاغط كاتم الصوت الفعال للعلامة التجارية العالمية وتقنية الرغوة الخاصة بالحالة الخاصة، ويتميز بضوضاء منخفضة واستهلاك منخفض للطاقة، وهو أكثر ملاءمة للأغراض العائلية والتجارية.

تذكير ودي:

إذا كان منتجك منتجاً محسناً، فقد يختلف قليلاً عن الإرشادات المقدمة. ومع ذلك، تأكد من أن أداءه وطريقة تطبيقه لا يتغيران. يمكنك الاستمرار في استخدامه بثقة.

تنبيهات: لا تستخدمى الثلجة في الأجواء الممطرة أو تحت أشعة الشمس المباشرة.

تنبيهات: لا تضع الحاويات التي تحتوي على سوائل على الثلجة، حيث أن كسر الحاوية أو قلبها قد يؤدي إلى إتلاف العزل الكهربائي للثلجة، مما يؤدي إلى حدوث صدمة كهربائية أو مخاطر الحريق.

تنبيهات: لا يجوز تفكيك الثلجة أو تعديلها بدون إذن. يجب أن يتم إصلاح الثلجة من قبل متخصص.

تنبيهات: في حالة تسرب أي غاز قابل للاشتعال مثل غاز الفحم، قم أولاً بإغلاق صمام التسرب، ثم افتح النافذة للتهوية. لا تقم بفصل موصل الثلجة على الفور لتجنب خطر نشوب حريق أو انفجار بسبب الشرر الكهربائي.

تنبيهات: قد لا تعمل أجهزة التبريد، وخاصة التلاجات والمجمدات من النوع الأول، بشكل ثابت إذا تم وضعها لفترة طويلة تحت الحد البارد لنطاق درجة الحرارة الذي تم تصميم الجهاز من أجله. قد يؤدي هذا إلى إذابة المحتويات أو ارتفاع درجة الحرارة بشكل كبير في حجرة الأطعمة المجمدة.

تنبيهات: لا ينبغي تخزين المشروبات الفوارة في حجرات أو خزائن تجميد الأطعمة، أو في حجرات أو خزائن ذات درجات حرارة منخفضة. بالإضافة إلى ذلك، لا ينبغي استهلاك بعض المنتجات، مثل الماء المثلج، عندما تكون باردة للغاية.

تنبيهات: لا تتجاوز فترات التخزين الموصى بها من قبل مصنعي الأغذية لأي نوع من الأطعمة.

تنبيهات: اتخذ الاحتياطات اللازمة لمنع حدوث ارتفاع غير مبرر في درجة حرارة الطعام المجمد أثناء إزالة الجليد من جهاز التبريد.

تنبيهات: إن ارتفاع درجة حرارة الأطعمة المجمدة أثناء إذابتها يدويًا أو صيانتها أو تنظيفها قد يؤدي إلى تقليل مدة تخزينها.

تنبيهات: تأكد من العناية المناسبة بتخزين الأطعمة المجمدة أثناء فترات طويلة عندما لا يعمل جهاز التبريد، مثل أثناء انقطاع التيار الكهربائي أو فشل نظام التبريد.

تنبيهات: تتضمن الخطوات التي يجب اتخاذها عند إيقاف تشغيل جهاز التبريد مؤقتًا أو بشكل دائم إفراغه وتنظيفه وتجفيفه، وترك الباب (الأبواب) أو الأغطية مفتوحة جزئيًا.



تحذير: خطر نشوب حريق/مواد قابلة للاشتعال

تحذير: عند وضع الجهاز، تأكد من عدم انحشار سلك الإمداد أو تلفه.

تحذير: تجنب وضع عدة منافذ كهربائية محمولة أو مصادر طاقة في الجزء الخلفي من الجهاز.

يسمح للأطفال من سن 3 إلى 8 سنوات بتحميل وتفريغ أجهزة التبريد

قد يؤدي فتح الباب لفترة طويلة إلى زيادة كبيرة في درجة الحرارة داخل حجرات الجهاز.

قم بتنظيف الأسطح التي تلامس الطعام وأنظمة الصرف المتاحة بانتظام.

نظف خزانات المياه إذا لم يتم استخدامها لمدة 48 ساعة؛ اغسل نظام المياه المتصل بمصدر المياه إذا لم يتم سحب المياه لمدة 5 أيام.

قم بتخزين اللحوم والأسماك النيئة في حاويات مناسبة في الثلاجة لمنع ملامستها أو تساقطها على الأطعمة الأخرى.

تعتبر حجرات الأطعمة المجمدة ذات النجمتين مناسبة لتخزين الأطعمة المجمدة مسبقًا، وتخزين الأيس كريم أو صنعه وصنع مكعبات الثلج.

الحجرات ذات النجمة الواحدة والنجمتين والثلاث نجوم غير مناسبة لتجميد الأطعمة الطازجة.

في حالة ترك جهاز التبريد فارغًا لفترات طويلة، قم بإيقاف تشغيله وإزالة الجليد منه وتنظيفه وتجفيفه واطرك الباب مفتوحًا لمنع تطور العفن داخل الجهاز.

2. تنبيهات

تنبيهات: يجب أن يتطابق مصدر الطاقة لهذا المنتج مع مصدر الطاقة المذكور على لوحة الاسم، ويجب استخدام مقيس قياسي مستقل ثلاثي الفتحاح بقوة تزيد عن 10 أمبير ومؤرض بشكل موثوق. تجنب مشاركة مقيس واحد بين أجهزة متعددة لتجنب ارتفاع درجة الحرارة ومخاطر الحرائق المحتملة.

تنبيهات: تجنب سحب سلك الطاقة باليد. قم دائمًا بإمسك موصل الطاقة وفصله من المقبس لفصل مصدر الطاقة. لا تلمس سلك الطاقة أو الموصل بأيدي مبللة لتجنب خطر التعرض لصدمة كهربائية.

تنبيهات: لا تسمح للثلاجة أو أي حمل ثقيل بالضغط على سلك الطاقة، وتجنب الانحناء الشديد لسلك الطاقة.

قد يؤدي تلف أو تقشر سلك الطاقة إلى نشوب حريق أو التعرض لخطر الصدمة الكهربائية.

إذا انكسر سلك الطاقة أو انقطع، يرجى الاتصال بقسم خدمة ما بعد البيع على الفور.

تنبيهات: لا تقم بتخزين أي مواد قابلة للاشتعال أو الانفجار، أو أحماض مسببة للتآكل، أو مواد قلووية في الثلاجة.

1. تحذير

تحذير: لا ينبغي وضع أي حاجز حول الجهاز أو داخل الهيكل المدمج لضمان التهوية الحرة.

تحذير: يمنع تسريع عملية إزالة الجليد باستخدام أي جهاز ميكانيكي أو أي طريقة أخرى غير تلك الموصى بها من قبل الشركة المصنعة.

تحذير: لا تلحق الضرر بدائرة التبريد.

تحذير: لا تستخدم الأجهزة الكهربائية داخل حجرات تخزين الطعام بالجهاز، إلا إذا كانت من النوع الموصى به من قبل الشركة المصنعة.

تحذير: لا تضع المشروبات الساخنة أو الأطعمة الموجودة في عبوات زجاجية داخل حجرة التجميد لتجنب تعرضها للكسر والتحطيم.

تحذير: إذا تم إيقاف تشغيل الثلاجة، فيجب تشغيلها مرة أخرى بعد 5 دقائق لمنع تلف الضاغط.

تحذير: إذا تم ملاحظة أي جزء متصل بالكهرباء أو ضوضاء غير طبيعية أو رائحة أو دخان أو أي تشوهات أخرى أثناء الاستخدام، فمن الضروري إيقاف تشغيل الجهاز على الفور والاتصال على الفور بقسم خدمة ما بعد البيع بالشركة.

تحذير: تجنب وضع إصبعك أو يدك تحت الثلاجة، وخاصة الجزء السفلي الخلفي، حيث قد تؤدي الأشياء الحادة إلى الإصابة.

تحذير: لا يجوز للأطفال اللعب أو التسلق على الثلاجة. يجب على الوالدين مراقبة الأطفال لمنع الخطر المحتمل.

تحذير: تجنب وضع يدك بين الأبواب لفتحها أو إغلاقها لتجنب انحناس أصابعك. استخدم دائمًا مقبض الباب لفتح الباب أو إغلاقه.

بالنسبة لأجهزة التبريد ذات فئة المناخ

اعتمادًا على فئة المناخ، تم تصميم جهاز التبريد هذا للاستخدام في نطاق درجات الحرارة المحيطة كما هو محدد في الجدول التالي.

يمكن العثور على فئة المناخ على لوحة التصنيف. قد لا يعمل المنتج بشكل صحيح في درجات حرارة خارج النطاق المحدد.

يمكنك العثور على فئة المناخ على الملصق الموجود داخل ثلاجتك

نطاق درجة الحرارة الفعال

تم تصميم الثلاجة لتعمل بشكل طبيعي في نطاق درجة الحرارة المحدد حسب تصنيف فتتها.

| نطاق درجة الحرارة المحيطة (درجة مئوية) | الرمز | الفئة |
|--|-------|-------------|
| +10 إلى +32 | SN | معتدل ممتد |
| +16 إلى +32 | N | معتدل |
| +16 إلى +38 | ST | شبه استوائي |
| +16 إلى +43 | T | استوائي |

ⓘ ملاحظة

قد يتأثر أداء التبريد واستهلاك الطاقة في الثلاجة بدرجة الحرارة المحيطة وتردد فتح الباب وموقع الثلاجة، لذا نوصي بضبط إعدادات درجة الحرارة حسب الاقتضاء.

| | |
|-----|--------------------------------|
| P2 | تعليمات السلامة..... |
| P5 | مقدمة المنتج..... |
| P6 | التعامل والوضع..... |
| P7 | الاستعدادات قبل الاستخدام..... |
| P8 | مفاتيح التشغيل..... |
| P11 | الرعاية والصيانة..... |
| P12 | تحليل العطل..... |
| P12 | عدم العطل..... |
| P13 | المعايير الفنية..... |
| P13 | قائمة التعبئة..... |

1. **هذا الجهاز غير مخصص للاستخدام من قبل الأشخاص (بما في ذلك الأطفال) الذين يعانون من ضعف القدرات الجسدية أو الحسية أو العقلية، أو من لديهم نقص في الخبرة والمعرفة، ما لم يتم الإشراف عليهم أو اعطاءهم التعليمات الخاصة باستخدام الجهاز من قبل شخص مسؤول عن سلامتهم. يجب الإشراف على الأطفال للتأكد من أنهم لا يلعبوا مع الجهاز.**
2. **في حالة تلف سلك الطاقة، يجب استبداله من قبل الشركة المصنعة أو وكيل الخدمة أو الأشخاص المؤهلين بالمثل لتجنب الخطر.**
3. **يمكن للأطفال الذين تبلغ أعمارهم 8 سنوات فأكثر والأشخاص ذوي القدرات البدنية أو الحسية أو العقلية المحدودة، أو الذين يفتقرون إلى الخبرة والمعرفة، استخدام هذا الجهاز، إذا تم الإشراف عليهم أو توجيههم فيما يتعلق بالاستخدام الآمن للجهاز وفهم المخاطر التي ينطوي عليها. لا يجب أن يلهو الأطفال بالجهاز. لا يجوز للأطفال القيام بأعمال التنظيف والصيانة دون إشراف.**
4. **تحذير: حافظ على فتحات التهوية، الموجودة في حاوية الجهاز أو في الهيكل المدمج، خالية من أي انسداد.**
5. **تحذير: لا تستخدم أجهزة ميكانيكية أو وسائل أخرى لتسريع عملية إزالة الجليد، بخلاف تلك الموصى بها من قبل الشركة المصنعة.**
6. **تحذير: لا تلحق الضرر بدائرة التبريد.**
7. **تحذير: لا تستخدم الأجهزة الكهربائية داخل حجرات تخزين الطعام بالجهاز، إلا إذا كانت من النوع الموصى به من قبل الشركة المصنعة.**
8. **لا تَمّ بتخزين المواد القابلة للانفجار مثل علب الأيروسول التي تحتوي على وقود قابل للاشتعال في هذا الجهاز.**
9. **يتم استخدام هذا الجهاز في التطبيقات المنزلية والتطبيقات المماثلة مثل:**
مناطق مطبخ الموظفين في المحلات التجارية والمكاتب وبيئات العمل الأخرى؛
المزارع وعملاء في الفنادق والموتيلات وغيرها من البيئات السكنية؛
بيئات الإقامة والإفطار؛
المطاعم والتطبيقات المماثلة غير المخصصة للبيع بالتجزئة.



MBM275-125T

الثلاجة دليل المستخدم

- الصور هي للإشارة فقط. المنتجات عرضة للتغيير دون إشعار.
- يرجى قراءة دليل التعليمات بعناية قبل الاستخدام والاحتفاظ به للرجوع إليه في المستقبل.

يرجى قراءة جميع التعليمات قبل استخدام هذا الجهاز